



Installation Instructions

CXTM SERIES GEOCELLS

www.CarthageMills.com

Reference Chart

Application	Non-woven Geotextile Underlayment	CX GEOCELLS	Cell Depth	Infill Type	Overfill Cell By This Amount	Additional Surface Layer If Required	Total Excavation
Gravel Paving	YES	CX20-2	2"	Aggregates:	2"	No Additional Surface Layer Required	4"
		CX20-3	3"	#57, #8, 7, 6,	2"		5"
		CX20-4	4"	CR-6, RC6,	2"		6"
		CX20-6	6"	#10	2"		8"
Pavers <small>(Note: for permeable system delete 1" sand, subtract from total excavation)</small>	YES	CX20-2	2"	Aggregates:	1"	1" Sand + 2.38" Paver	6.38"
		CX20-3	3"	#57, #8, 7, 6,	1"	1" Sand + 2.38" Paver	7.38"
		CX20-4	4"	CR-6, RC6,	1"	1" Sand + 2.38" Paver	8.38"
		CX20-6	6"	#10	1"	1" Sand + 2.38" Paver	10.38"
Grass Paving	YES	CX20-3	3"	Engineered fill of 30% topsoil	1"	2" Grass/Turf	6"
		CX20-4	4"	70% washed gravel	1"	2" Grass/Turf	7"
		CX20-6	6"		1"	2" Grass/Turf	9"

Installation Instructions

1. Lay out job prior to excavation.
2. Remove all vegetation, debris or pavement.
3. Excavate existing soil to appropriate depth (see chart).
4. Prep subgrade. Use gravel to level any areas if desired.




5. Install non-woven geotextile fabric overlapping by a minimum of 12" at the seams.



6. Lay out stakes.
 - 4 stakes should be placed at each corner of expanded Grid dimensions.
 - You should have a stake in each corner.**NOTE:** Grid can be cut with any cutting tool to any shape or size as needed to fit the job site.



7. Unpack Grid.
 - Remove bands with any cutting tool.
 - Unfold the Grid.**NOTE:** If using more than one piece of Grid refer to back page showing connection instructions.



8. Expand Grid past each stake to uniformly expand all cells and then relax the Grid allowing the corner cells to be placed over installed stakes. Add stakes as necessary.



9. Continue to add stakes or simply fill gravel in perimeter cells as needed to ensure proper expansion.



10. Begin filling cells with infill (see chart for specified material).
- To prevent any damage to the Grid, limit the drop height of infill to no more than 3ft.



11. Machine infill.
- It is safe to drive on cells that have been completely filled.



CAUTION: Do not twist machine tracks on Grid.

12. Rake or blade compact the infill to specified dimensions over top of cells (see chart for dimensions).



13. Compact infill with a plate compactor or a plate tamper.



COMPLETED:
Gravel Installation


For Paver Installation

Continue with desired method:
- Traditional method: screed sand and lay pavers.
- Permeable method: lay permeable pavers.




Grid Connection

Connection Type 1 - Cell Wall to Cell Wall



Connection Type 2 - Weld End to Weld End



Staple Connection

Pneumatic Stapler




OR




Hand Held Stapler

Type 1 - Cell Wall Connection



Type 2 - Weld End Connection



- Use heavy
duty staples

Contact Information

Carthage Mills

4243 Hunt Road
Cincinnati, OH 45242
www.carthagemills.com

513-794-1600 TELEPHONE
800-543-4430 TOLL FREE
513-794-3434 FACSIMILE



Since 1958: America's *First* Geotextile Company